

Word Windows

Instructions of use.

Thank you for purchasing the Word Window. We hope that you and your child enjoy using it and that our handy tips and resources make reading at home with your child a fun and more enjoyable experience.



Remove from the box, dispose of the packaging using your local recycling facilities.



Hold the Word Window in your dominant hand. Your fingers should be placed in-line with the brand name on the left hand arm of the device. This is to avoid unnecessary pressure at the base of the product.



By squeezing the arms together you can open and close the window so that you can isolate letters and sounds in the words that your child is struggling to read.

Step 4

Visit the resources section on the website where you can find activity sheets and certificates to motivate and celebrate your child's efforts.

You can also join our community and find helpful videos on our YouTube channel - details on the homepage.

www.thewordwindow.com ©